

Bettis CB/CBx & G-Series

IEC 61508 SIS/SIL Safety Manual

Table of Contents

Section 1: Scope

Section 2: Purpose

Section 3: Topics

3.1	Safety function.....	6
3.2	Proof test procedure	6
3.3	Repair/Replace procedure	6
3.4	Installation and site acceptance prodecure.....	6
3.5	Application and environmental limits	6
3.6	Periodic maintenance requirements	6
3.7	Hardware version	7
3.8	Settings	7
3.9	Functional safety data	7
3.10	Archievable SIL statement	7
3.11	Product lifetime limits.....	7

Section 4: Installation, Operation & Maintenance Manual, IOM

Section 5: Technical Files

Section 1: Scope

All Bettis brand CB/CBx & G-series products currently SIS/SIL certified by EXIDA using IEC 61508 guidelines.

Section 2: Purpose

To ensure all the applicable safety requirements of IEC 61508 are complied with, thereby ensuring current certified SIS/SIL levels are maintained.

Section 3: Topics

3.1 Safety function

The CB/CBx Series and G Series actuators rotate with sufficient torque to move a valve to its fail-safe state when hold-position air released.”

The Bettis brand Actuator Selection Procedure provides functional definition with specifics on input variables and performance.

3.2 Proof test procedure

Proof Test procedure and proof test coverage are part of the FMEDA reports which are provided to those requiring SIS functionality, see exida report nos. EAS 16/06-010 R001 and R002. No specific tools are required for proof testing. Individual who will perform the proof test is expected to be trained in actuator maintenance.

3.3 Repair/Replace procedure

Procedures to repair or replace the CB/CBx Series and G Series actuators are provided in the respective IOM, see Section 4 for a listing of Bettis IOM document numbers.

Please refer to the IOM for any tools required for repair and replacement and required competency of technicians. Maintenance and subsequent test procedures are also covered in the IOM's. Any failures, identified by the end-user during maintenance, repair or proof testing, that potentially impact the functional safety of the CB/CBx Series and G Series actuators should be reported back to Valve Automation Customer Service Coordinator.

3.4 Installation and site acceptance procedure

Any necessary installation and site acceptance procedures are discussed in the CB/CBx Series and G Series actuators IOM listed in Section 4. IOM defines exercising of the actuator after installation. The IOMs also define testing after maintenance.

3.5 Application and environmental limits

All application and environmental limits need to be observed for the CB/CBx Series and G Series Actuators. Please observe the pressures and temperatures that are stamped on the nameplate per European Directives.

More information can be found in the Bettis Technical Files listed in Section 5.

3.6 Periodic maintenance requirements

For the CB/CBx Series and G Series actuators the periodic maintenance requirements should be observed, refer to the IOM documents listed in Section 4. A 5-year normal maintenance interval is defined for the CB/CBx Series and G Series actuators.

3.7 Hardware version

The hardware version of the actuator can be identified from the nameplate on the actuator.

3.8 Settings

Installation and maintenance settings for the CB/CBx Series and G Series actuators are specified in the IOMs. There are not specific safety settings to be made.

3.9 Functional safety data

Users applying the actuators in functional safety applications should contact Bettis to obtain the assessment and FMEDA report, which include failure data, a sample PFDavg calculation, and other associated statistical data to establish or satisfy SIL level requirements. This information is available in exida reports EAS 16/06-010 R001, R002 and R003 for G FMEDA, CB FMEDA and assessment respectively.

3.10 Achievable SIL statement

The CB/CBx Series and G Series actuator have been assessed per the relevant requirements of IEC 61508, Parts 1 and 2. They provided systematic integrity up to SIL 3. For random integrity they have been designated as Type A devices with Hardware Fault Tolerance (HFT) = 0. PFDavg and Architectural Constraints must be verified for each final element application. When using the CB/CBx Series and G Series actuator in a redundant configuration, a common cause factor of at least 5% should be included in safety integrity.

3.11 Product lifetime limits

The IOM defines a 5-year minimum maintenance interval for the CB/CBx Series and G Series actuators. This addresses components that may have age related degradation. The remaining components are not age sensitive. Please also refer to the FMEDA reports, exida report nos. EAS 16/06-010 R001 and R002 for the useful life of the actuators.

Section 4: Installation, Operation & Maintenance Manual, IOM

- 137464 CBA/CBB 315, 420, 520, 525 & 725 double-acting models
- 137465 CBA/CBB 315, 415, 420, 520, 525 & 725 spring-return models
- 137462 CBA730, 830, 930 & 1030 double-acting models
- 137463 CBA730, 830, 930 & 1030 spring-return models
- 068269 CB315, 420, 520, 525 & 725 double-acting models
- 068270 CB315, 415, 420, 520, 525 & 725 spring-return models
- 124840 G-series pneumatic models
- 124841 G-series pneumatic models with tandem power cylinders
- 124843 G-series double-acting pneumatic models with M11 hydraulic override
- 127073 G-series spring-return pneumatic models with M11 hydraulic override
- 127215 G-series pneumatic models w/tandem power cylinders & M11 hydraulic override

Section 5: Technical Files

- 136360 CB/CBA x15, x20 & x25 models for pneumatic service
- 136373 G-series models for pneumatic service
- 137569 G-series models for hydraulic service

World Area Configuration Centers (WACC) offer sales support, service, inventory and commissioning to our global customers. Choose the WACC or sales office nearest you:

NORTH & SOUTH AMERICA

19200 Northwest Freeway
Houston TX 77065
USA
T +1 281 477 4100

Av. Hollingsworth
325 Iporanga Sorocaba
SP 18087-105
Brazil
T +55 15 3413 8888

ASIA PACIFIC

No. 9 Gul Road
#01-02 Singapore 629361
T +65 6777 8211

No. 1 Lai Yuan Road
Wuqing Development Area
Tianjin 301700
P. R. China
T +86 22 8212 3300

MIDDLE EAST & AFRICA

P. O. Box 17033
Jebel Ali Free Zone
Dubai
T +971 4 811 8100

P. O. Box 10305
Jubail 31961
Saudi Arabia
T +966 3 340 8650

24 Angus Crescent
Longmeadow Business Estate East
P.O. Box 6908 Greenstone
1616 Modderfontein Extension 5
South Africa
T +27 11 451 3700

EUROPE

Holland Fisor 6
Székesfehérvár 8000
Hungary
T +36 22 53 09 50

Strada Biffi 165
29017 Fiorenzuola d'Arda (PC)
Italy
T +39 0523 944 411

For complete list of sales and manufacturing sites, please visit www.emerson.com/actuationtechnologieslocations or contact us at info.actuationtechnologies@emerson.com

www.emerson.com/bettis

©2017 Emerson. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Bettis™ is a mark of one of the Emerson family of companies. All other marks are property of their respective owners.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

BETTIS™

